




# OWNER/OPERATOR MANUAL

## HEDGE-TRIMMERS

### HT2200 CHT2200



#### WARNING



The engine exhaust from this product contains chemicals known to the State of California to cause cancer, birth defects or other reproductive harm.

Thank you for purchasing a RedMax product.

Before using our hedge-trimmers, please read this manual carefully to understand the proper use of your unit.

#### APPLICABLE SERIAL NUMBERS :


HT2200	CUTTING UNIT 900101 and up	ENGINE UNIT 50100000 and up
CHT2200	CUTTING UNIT 900101 and up	ENGINE UNIT 50100000 and up



**Read this manual carefully to understand all safety precautions, controls, proper operation and maintenance of your RedMax hedge-trimmers. Failure to do so could result in serious injury.**



## **SAFETY FIRST**

Instructions contained in warnings within this manual marked with a  symbol concern critical points which must be taken into consideration to prevent possible serious bodily injury, and for this reason you are requested to read all such instructions carefully and follow them without fail.

Note that there may be times when warning seals peel off or become soiled and impossible to read. If this happens, you should contact the dealer from which you purchased the product to order new seals and affix the new seal(s) in the required location(s).

### **■ Notes on types of warnings**



Instructions labeled as shown at left, concern critical steps or procedures which must be followed in order to prevent accidents which could lead to serious bodily injury or death. This mark is used to indicate instructions which must be followed without exception.



Instructions labeled as shown at left concern steps or procedures which, if not followed correctly, could lead to mechanical failure, breakdown, or damage.



Used to label supplementary instructions designed to provide hints or directions useful in the use of the product.

# CONTENTS

<b>SAFETY PRECAUTIONS</b> .....	<b>4</b>
PROPER AND SAFE OPERATION OF YOUR HEDGE-TRIMMER	
WORK GEAR AND CLOTHING	
WARNINGS CONSIDERING HANDLING OF FUEL	
THINGS TO CHECK BEFORE USING YOUR HEDGE-TRIMMER	
THINGS TO CHECK BEFORE STARTING UP THE ENGINE	
AVOID NOISE PROBLEM	
THINGS TO BE CAREFUL ABOUT WHEN USING YOUR HEDGE-TRIMMER	
NOTES ON CARE AND MAINTENANCE OF YOUR HEDGE-TRIMMER	
<b>PARTS LOCATION &amp; SPECIFICATIONS</b> .....	<b>9</b>
<b>EMISSION CONTROL LABEL</b> .....	<b>10</b>
<b>SET UP</b> .....	<b>11</b>
HT2200	
CHT2200	
<b>FUEL</b> .....	<b>13</b>
HOW TO MIX FUEL	
FUELING THE UNIT	
<b>OPERATION</b> .....	<b>15</b>
STARTING ENGINE	
STOPPING ENGINE	
ADJUSTING IDLING SPEED	
HOW TO USE	
<b>MAINTENANCE</b> .....	<b>17</b>
DAILY INSPECTION	
GEAR CASE	
AIR FILTER	
FUEL FILTER	
SPARK PLUG	
MUFFLER	
SPARK ARRESTER	
INTAKE AIR COOLING VENT	
PROCEDURES TO BE PERFORMED AFTER EVERY 100 HOURS OF USE	
<b>STORAGE</b> .....	<b>20</b>
<b>PARTS LIST</b> .....	
HT2200 .....	<b>22</b>
CHT2200 .....	<b>26</b>



## Safety Precautions

### ■ IN ORDER TO ENSURE PROPER AND SAFE OPERATION OF YOUR HEDGE-TRIMMER


- Read this Owner/Operator Manual carefully. Be sure you understand how to operate this unit properly before you use it. Failure to do so could result in serious injury.



- Be sure to keep this manual handy so that you may refer to it later whenever any questions arise. Also note that you are requested to contact the dealer from whom you purchased the product for assistance in the event that you have any questions which cannot be answered herein.
  - Always be sure to include this manual when selling, lending, or otherwise transferring the ownership of this product.
- This product has been designed for use in trimming leaves and branches from trees and hedges, and it should never be used for any other purpose since doing so could result in unforeseen accidents and injuries occurring.
- This product is equipped with extremely sharp blades, and when used improperly these blades can be extremely dangerous. For this reason, you should never use this hedge-trimmer when under the influence of alcohol, when suffering from exhaustion or lack of sleep, when suffering from drowsiness as a result of having taken cold medicine, or at any other time when a possibility exists that your judgment might be impaired or that you might not be able to operate the hedge-trimmer properly and in a safe manner. Also be sure never to allow children or anyone unable to fully understand the directions given in this manual to use this hedge-trimmer.



- Avoid running the engine indoors. The exhaust gases contain harmful carbon monoxide.




- Never use your hedge-trimmer under circumstances like those described below:
  1. When the ground is slippery or when other conditions exist which might make it not possible to maintain a steady posture while using the hedge-trimmer.
  2. At night, at times of heavy fog, or at any other times when your field of vision might be limited and it would be difficult to gain a clear view of the area where the hedge-trimmer is to be used to ensure safety.
  3. During rain storms, during lightning storms, at times of strong or gale-force winds, or at any other times when weather conditions might make it unsafe to use this product.
- When using this product for the first time, before beginning actual work, take the hedge-trimmer to a wide, clear, open space, turn on the power, and practice handling the hedge-trimmer until you are sure that you will be able to handle it properly in actual operation.
- Lack of sleep, tiredness, or physical exhaustion results in lower attention spans, and this in turn leads to accidents and injury. When planning your work schedule, allow plenty of time to perform the work of trimming and allow plenty of time for rest. Limit the amount of time over which the hedge-trimmer is to be used continuously to somewhere around 30~40 minutes per session, and take 10~20 minutes of rest between work sessions. Also try to keep the total amount of work performed in a single day under 2 hours or less.



## Safety Precautions

### ■ WORK GEAR AND CLOTHING

- When using your hedge-trimmer, always be sure to wear strong, durable, work clothing; shirts should be long-sleeved shirts and pants should be full-length pants reaching down to the ankles.
- Always be sure to wear a helmet and face protector when using your hedge-trimmer.
- When using your hedge-trimmer, always be sure to wear thick work gloves to protect your hands and non-slip-sole work boots to prevent you from slipping. Never use your hedge-trimmer when wearing pants with loose cuffs, when wearing sandals, or when barefoot.
- When using your hedge-trimmer for an extended period of time, you should wear ear protectors to protect yourself from loss of hearing from overexposure to high levels of sound.



### ■ WARNINGS CONSIDERING HANDLING OF FUEL

- The engine of the RedMax hedge-trimmer is designed to run on a mixed fuel which contains highly flammable gasoline. This fuel is highly flammable and you should never store cans of fuel or refill the tank of the hedge-trimmer in any place where there is a boiler, stove, wood fire, electrical sparks, welding sparks, or any other source of heat or fire which might ignite the fuel.



- Smoking while operating the hedge-trimmer or refilling its fuel tank is extremely dangerous. Always be sure to keep lit cigarettes away from the hedge-trimmer at all times.
- When refilling the tank always turn off the engine first and take a careful look around to make sure that there are no sparks or open flames anywhere nearby before refueling.
- If any fuel spillage occurs during refueling, always be sure to use a dry rag to wipe any fuel which has been spilled onto the hedge-trimmer before turning the engine back on again.
- After refueling, screw the fuel cap back tightly onto the fuel tank and then carry the hedge-trimmer to a spot 10 feet or more away from where it was refueled before turning on the engine.




## **Safety Precautions**

### ■ THINGS TO CHECK BEFORE USING YOUR HEDGE-TRIMMER

- Before beginning work, look around carefully to get a feel for the shape of the land, the trees, or hedges to be trimmed, and whether or not there are any obstacles which might get in the way while working, and remove any obstacles which can be cleared away before beginning work.
- The area within a perimeter of 45 feet of the person using the hedge-trimmer should be considered a hazardous area into which no one should enter while the hedge-trimmer is in use, and when necessary yellow warning rope, warning signs, or some other form of warnings should be placed around the perimeter of the area. When work is to be performed simultaneously by two or more persons, care should also be taken to constantly look around or otherwise check for the presence and locations of other people using hedge-trimmers within the work area so as to maintain a distance between each person sufficient to ensure safety.
- Before beginning work, each component of the hedge-trimmer should be checked to make sure that it is in proper working order and to make sure that there are no loose screws or bolts, fuel leaks, ruptures, dents, or any other problems which might interfere with safe operation. Be especially careful at this time to check that there is nothing wrong with the blades or with the joints by which the blades are attached to the hedge-trimmer.
- Never use the hedge-trimmer when the blades have been worn down severely or when there is any sort of damage which has occurred to the blade mechanism.
- Check to make sure that the handle grip and the protective cover have not come loose before using the hedge-trimmer.

### ■ THINGS TO CHECK BEFORE STARTING UP THE ENGINE

- Take a careful look around to make sure that no obstacles exist within a perimeter of 15 feet or less around the hedge-trimmer before starting the engine.



- The RedMax hedge-trimmer is equipped with a centrifugal clutch mechanism which causes the cutting blades to begin to rotate as soon as the engine is started by putting the throttle into the start position. When starting the engine, place the body of the hedge-trimmer onto the ground in a flat clear area and hold it firmly in place so as to ensure that neither the blades nor the throttle come into contact with any obstacles when the engine starts up.
- Never place the throttle into the high speed position when starting the engine.
- After starting up the engine, check to make sure that the blades stop rotating when the throttle is moved fully back to its original position. If the blades continue to rotate even after the throttle has been moved fully back, turn off the engine and take the unit to your authorized RedMax servicing dealer for repair.

### ■ AVOID NOISE PROBLEM

#### **NOTE**

**Check and follow the local regulations as to sound level and hours of operations for hedge-trimmer.**

- In general, operate hedge-trimmers between 8a.m. and 5p.m. on week days and 9a.m. to 5p.m. weekends. Avoid using hedge-trimmer late at night and/or early in the morning.



## **Safety Precautions**


### **■ THINGS TO BE CAREFUL ABOUT WHEN USING YOUR HEDGE-TRIMMER**

- When using your hedge-trimmer, grip the handles of the hedge-trimmer firmly with both hands, place your feet slightly apart (slightly further apart than the width of your shoulders) so that your weight is distributed evenly across both legs, and always be sure to maintain a steady, even posture while working.
- Maintain the speed of the engine at the level required to perform trimming work, and never raise the speed of the engine above the level necessary.
- Always be sure never to allow other persons to come within the work area while trimming.
- Be especially careful not to slip if it is raining or if rain has just stopped, as the ground is likely to be slippery at such times.
- If a branch or other object gets caught in the blades during operation, always be sure to turn off the engine before removing the object.
- Guard against hazardous situations at all times. Warn adults to keep pets and children away from the area. Establish a safe method for gaining your attention during operation. Be careful if you are approached.
- To protect yourself against injury from falling branches, always be sure to wear the required safety equipment, and be careful when working to watch to see in which direction branches are moving and falling so as to avoid being hit by falling branches.
- If someone calls out or otherwise interrupts you while working, always be sure to turn off the engine before turning around.
- Keep operation area clear of all persons, particularly small children and pets. Injury may result from flying debris.

- Never touch the spark plug or plug cord while the engine is in operation. Doing so may result in being subjected to an electrical shock.



- Never touch the muffler, spark plug, or other metallic parts of the engine while the engine is in operation or immediately after shutting down the engine. These metallic parts reach high temperatures during operation and doing so could result in serious burns.



- When you finish trimming in one location and wish to continue work in another spot, turn off the engine, place the protective cover over the blades, and turn the hedge-trimmer so that the blades face away from your body before carrying it to the new location.
- Never transport the hedge-trimmer over rough roads over long distances without first removing all fuel from the fuel tank, as doing so might cause fuel to leak from the tank as a result of shocks absorbed during transport.




## ***Safety Precautions***

### **■ NOTES ON CARE AND MAINTENANCE OF YOUR HEDGE-TRIMMER**

- In order to maintain your hedge-trimmer in proper working order, perform the maintenance and checking operations described in this manual at regular intervals. In the event that any parts must be replaced or any maintenance or repair work not described in this manual must be performed, please contact a representative from the store nearest RedMax authorized servicing dealer for assistance.
- Under no circumstances should you ever take apart the hedge-trimmer or alter it in any way. Doing so might result in the hedge-trimmer becoming damaged during operation or the hedge-trimmer becoming unable to operate properly.
- Always be sure to turn off the engine before performing any maintenance or checking procedures.
- When sharpening, removing, or reattaching the blades, be sure to wear thick, sturdy gloves and use only proper tools and equipment to prevent injury.
- When replacing blades or any other parts or when replacing the oil or any lubricants, always be sure to use only RedMax products or products which have been certified by RedMax for use with the RedMax hedge-trimmer.
- Do not use any accessory or attachment other than those bearing the RedMax mark and recommended for the unit.



# Parts Location & Specifications



## ■ HT2200

Type	Reciprocating single-sided dual blades
Blade size	24 (in)
Dry weight	9.5 (lbs)
Engine	Type Air-cooled 2-stroke gasoline
	Model Zenoah G23LH
	Displacement 22.5(cc)
	Fuel Mixture(Gasoline 50:Oil 1)
	Carburetor Walbro Diaphragm type
	Spark plug Champion RCJ6Y
Fuel tank capacity	20 (fl.oz)
Transmission	Centrifugal clutch, Cam-crank
Reduction ratio	4.33

## ■ CHT2200

Type	Reciprocating duple-sided dual blades
Blade size	22 (in)
Dry weig	9.5 (lbs)
Engine	Type Air-cooled 2-stroke gasoline
	Model Zenoah G23LH
	Displacement 22.5(cc)
	Fuel Mixture(Gasoline 50:Oil 1)
	Carburetor Walbro Diaphragm type
	Spark plug Champion RCJ6Y
Fuel tank capacity	20.(fl.oz)
Transmission	Centrifugal clutch, Cam-crank
Reduction ratio	4.33

Specifications are subject to change without notice.

# Emission Control Label

---

## IMPORTANT ENGINE INFORMATION

THIS ENGINE CONFORMS TO 2005 U.S. EPA  
REGULATIONS FOR SMALL NONROAD ENGINES.

COMPLIANCE PERIOD : CATEGORY A

**ENGINE FAMILY : 5KZXS. 0254CD : EM**

**ENGINE DISPLACEMENT : 23cc**

REFER TO OWNER'S MANUAL FOR MAINTENANCE  
SPECIFICATIONS AND ADJUSTMENTS.

### MANUFACTURED:



KOMATSU ZENOAH CO.

RedMax MADE IN JAPAN

## INFORMATION IMPORTANTE CONCERNANT LE MOTEUR

CE MOTEUR EST CONFORME A LA REGLEMENTATION  
U.S. EPA 2005 POUR LES PETITS MOTEURS HORS-ROUTE.

DUREE DE CONFORMITE : CATEGORIE A

**TYPE DE MOTEUR : 5KZXS.0254CD ; EM**

**CYLINDREE DU MOTEUR : 23 cc**

SE REFERER AU MANUEL DE L'UTILISATEUR POUR LES  
SPECIFICATIONS D'ENTRETIEN ET LES REGLAGES.

### FABRIQUE PAR :




KOMATSU ZENOAH CO.

RedMax MADE IN JAPAN


# Set up

## ■ HT2200

1. Join the engine unit to the clutch housing of the cutter unit, with the fuel tank on the blade side.
2. Align the mounting holes and tighten the engine securely with the 3 screws.




3. Remove the right handle mounting screw, nut, and washer casually attached on the blade beam.
4. Set the right handle on the beam making the grip come to the opposite side of the cutting teeth, and attach with the hardware removed before. When fastening the nut, hold the screw to keep the blade washer loose.




### NOTE

- To assure designed cutting performance, always keep a half spare turn for the blade screws. Over tightening will cause blade seizure and premature wear of the clutch system. Too loose screws will make the gap between the blades large, and result in poor cutting performance.


5. Install the left handle to the bracket attached to the clutch housing. Use the hardware as shown below.



7. Cover the throttle cable with colgate tube. Connect the throttle cable and the switch wire. Hold the wires at the lower part of the handle using the tie band.




8. Check the cable play and, if necessary, adjust between .04" and .08" by bending throttle wire receiver of the bracket with needle nose pliers.




## Set up

### ■ CHT2200


1. Attach the engine to the clutch housing of the cutter unit. Casually fix the front 2 points with the screws(.55" long).
2. After connecting the ground wire, install the rear handle to the clutch housing with the screw(2" long) and the nut.
3. Put the screw(1.6" long) through the ground wire terminal and the rear handle, and in to the engine mounting base. Securely tighten all of the engine mounting screws.
4. Attach the front handle onto the gear housing and fasten with 2 screws(1.2" long) and nuts.



5. Connect the throttle cable with the lever on the rear handle, and secure the end with the hardware attached to the handle.



6. Check the cable play and, if necessary, adjust between .04" and .08" by bending throttle wire receiver of the bracket with needle nose pliers.




# Fuel

## ⚠ WARNING

- Gasoline is very flammable. Avoid smoking or bringing any flame or sparks near fuel. Make sure to stop the engine and allow it cool before refueling the unit. Select outdoor bare ground for fueling and move at least 3m (10ft) away from the fueling point before starting the engine.



- The RedMax engines are lubricated by oil specially formulated for air-cooled 2-cycle gasoline engine use. If RedMax oil is not available, use an anti-oxidant added quality oil expressly labeled for air-cooled 2-cycle engine use. (JASO FC GRADE OIL or ISO EGC GRADE)
- Do not use BIA or TCW (2-stroke water-cooling type) mixed oil.



## ■ RECOMMENDED MIXING RATIO GASOLINE 50:OIL 1

### 50:1 MIXING CHART

GASOLINE	gal.	1	2	3	4	5
2-CYCLE OIL	fl.oz	2.6	5.2	7.8	10.4	13

GASOLINE	liter	1	2	3	4	5
2-CYCLE OIL	ml	20	40	60	80	100

- Exhaust emission are controlled by the fundamental engine parameters and components(eq., carburation, ignition timing and port timing) without addition of any major hardware or the introduction of an inert material during combustion.
- These engines are certified to operate on unleaded gasoline.
- Make sure to use gasoline with a minimum octane number of 89 RON (USA/Canada: 87AL)
- If you use a gasoline of a lower octane value than prescribed, there is a danger that the engine temperature may rise and an engine problem such as piston seizing may consequently occur.
- Unleaded gasoline is recommended to reduce the contamination of the air for the sake of your health and the environment.
- Poor quality gasolines or oils may damage sealing rings, fuel lines or fuel tank of the engine.

## ■ HOW TO MIX FUEL

### IMPORTANT

Pay attention to agitation.

- Measure out the quantities of gasoline and oil to be mixed.
- Put some of the gasoline into a clean, approved fuel container.
- Pour in all of the oil and agitate well.
- Pour In the rest of gasoline and agitate

again for at least one minute. As some oils may be difficult to agitate depending on oil ingredients, sufficient agitation is necessary for the engine to last long. Be careful that, if the agitation is insufficient, there is an increased danger of early piston seizing due to abnormally lean mixture.

5. Put a clear indication on the outside of the container to avoid mixing up with gasoline or other containers.
6. Indicate the contents on outside of container for easy identification.

## ■ FUELING THE UNIT

1. Untwist and remove the fuel cap. Rest the cap on a dustless place.
2. Put fuel into the fuel tank to 80% of the full capacity.
3. Fasten the fuel cap securely and wipe up any fuel spillage around the unit.

## WARNING

1. Select bare ground for fueling.
2. Move at least 10feet (3meters) away from the fueling point before starting the engine.
3. Stop the engine before refueling the unit. At that time, be sure to sufficiently agitate the mixed gasoline in the container.

## FOR YOUR ENGINE LIFE, AVOID;

1. FUEL WITH NO OIL(RAW GASOLINE) – It will cause severe damage to the internal engine parts very quickly.
2. GASOHOL – It can cause deterioration of rubber and/or plastic parts and disruption of engine lubrication.
3. OIL FOR 4-CYCLE ENGINE USE – It can cause spark plug fouling, exhaust port blocking, or piston ring sticking.
4. **Mixed fuels which have been left unused for a period of one month or more** may clog the carburetor and result in the engine failing to operate properly.

5. In the case of storing the product for a long period of time, clean the fuel tank after rendering it empty. Next, activate the engine and empty the carburetor of the composite fuel.
6. In the case of scrapping the used mixed oil container, scrap it only at an authorized repository site.

## NOTE

As lot details of quality assurance, read the description in the section Limited Warranty carefully. Moreover, normal wear and change in product with no functional influence are not covered by the warranty. Also, be careful that, if the usage in the instruction manual is not observed as to the mixed gasoline, etc. described therein, it may not be covered by the warranty.


# Operation

## ■ STARTING ENGINE

### **⚠ WARNING**


- **Keep the blades clear of the surrounding as they will start moving upon starting of the engine.**

1. When first starting up after putting fuel into the machine, push the priming pump until fuel runs out in the clear tube. Then close the choke. Choking may not be necessary when re-starting right after stopping the engine.



PRIMING PUMP

2. Pull the throttle lever and push the lock button to set the lever in the START position.



[CHT2200]

THROTTLE LEVER


THROTTLE LEVER




[HT2200]

LOCK BUTTON

3. Slide the ignition switch to the engine side to set it in the ON position.




[CHT2200]




[HT2200]

4. Rest the unit on a firm place. Pull the starter knob quickly.



[CHT2200]



[HT2200]

### **NOTE**

- Avoid pulling the rope to its end or returning it by releasing the knob. Such actions can cause starter failures.

5. When the engine has started, gradually open the choke.

6. Allow the engine to warm up for a half minute before starting operation.


### **NOTE**

- If the engine won't start after several attempts, open the choke and repeat pulling the rope or remove the spark plug and dry it.


# Operation

## ■ STOPPING ENGINE

1. Release the throttle lever and run the engine at idling speed for a half minute.
2. Slide the ignition switch to the STOP position.



[CHT2200]




[HT2200]

### NOTE

- Except for an emergency, avoid stopping the engine while running it at high speed.

## ■ ADJUSTING IDLING SPEED

1. When the engine tends to stop frequently at idling mode, turn the idle set screw clock-wise.
2. When the cutting blades keep moving after releasing the throttle trigger, turn the idle set screw counter-clockwise.



### NOTE

- Warm up the engine before adjusting the idling speed.

## ■ HOW TO USE

- **This machine is designed so as to cut twigs upto 8 mm(0.3 inches) thick. Cutting too thick twigs or metal wires can not only break the blade teeth but also give damage to the drive mechanism.**
- When trimming leaves and thin twigs, guide the blades as drawing a half circle on the surface, and you will get a better finish.
- Running the engine at high speed with the blades Jammed up can shorten the life of clutch parts. When the blades have been jammed by thick twigs, stop operation at once and draw your unit off the objects after stopping the engine. When clipping comparatively thick twigs, move your unit slowly back and forth like a saw, and they can be cut to a fine finish.

### NOTE

- When a new unit is first operated, in the first few minutes grease may come out of the gear case. But, since this is excess grease, there is no cause for alarm. For next use just wipe it off with the engine stopped.



# Maintenance

Maintenance, replacement, or repair of the emission control device and systems may be performed by any non-road engine repair establishment or individual.

## ⚠ WARNING

- Make sure that the engine has stopped and is cool before performing any service to the hedge-trimmer. Contact with moving cutting head or hot muffler may result in a personal injury.

## ■ DAILY INSPECTION


- Check all the fasteners for loose or missing ones.
- Brush off dirt on the blades and apply a light coating of oil.

## NOTE

- The blades are loose-installed to the guide bar with several screws and nuts. Do not tighten up those screws, or the blades will be locked and result in clutch failures. Allow the screws a half spare turn, and secure there with the nut(See NOTE on page 8).


## ■ GEAR CASE

- At every 15 hours of use, supply grease to the gear case. Pump in grease via the grease fitting until it comes out of the root of blades.



## ■ AIR FILTER

- The air filter, if clogged, will reduce the engine performance. Monthly check and clean the filter element in warm, soapy water as required. Dry completely before installing. If the element is broken or shrunk, replace with a new one.




## ■ FUEL FILTER

- When the engine runs short of fuel supply, check the fuel cap and the fuel filter for blockage.

## ■ SPARK PLUG

- Starting failure and mis-firing are often caused by a fouled spark plug. Periodically clean the spark plug and check that the spark gap is in the correct range. For a replacement plug, use the correct type specified by RedMax(See SPECIFICATIONS on the page 15).



- **REPLACEMENT PLUG IS A CHAMPION RCJ6Y OR THE EQUIVALENT, SUCH AS BOSCH WR8E OR NGK BR6S.**

## IMPORTANT

- Note that using any spark plugs other than those designated may result in the engine failing to operate properly or in the engine becoming overheated and damaged.
- To install the spark plug, first turn the plug until it is finger tight, then tighten it a quarter turn more with a socket wrench.

# Maintenance


## ■ MUFFLER

### ⚠ WARNING

- Inspect periodically, the muffler for loose fasteners, any damage or corrosion. If any sign of exhaust leakage is found, do not use the hedge-trimmer and have it repaired immediately.
- **Note that failing to do so may result in the engine catching on fire.**

## ■ SPARK ARRESTER

- The muffler is equipped with a spark arrester to prevent red hot carbon from flying out of the exhaust outlet. Periodically inspect and clean as necessary with a wire brush. In the State of California it is required by law (Section 4442 of the California Public Resources Code) to equip a spark arrester when a gas powered tool is used in any forest covered, brush covered, or grass covered unimproved land.



## ■ INTAKE AIR COOLING VENT

### ⚠ WARNING


- **Never touch the cylinder, muffler, or spark plugs with your bare hands immediately after stopping the engine. The engine can become very hot when in operation, and doing so could result in severe burns.**
- When checking the hedge-trimmer to make sure that it is okay before using it, check the area around the muffler and remove any wood chips or leaves which have attached themselves to the hedge-trimmer. Note that failing to do so could cause the muffler to become

overheated, and that this in turn could cause the hedge-trimmer to catch on fire. **Always make sure that the muffler is clean and free of wood chips, leaves, and other waste before use.**

- Check the intake air cooling vent and the area around the cylinder cooling fins after every 25 hours of use for blockage, and remove any waste which has attached itself to the hedge-trimmer. Note that it is necessary to remove the plug guard shown below in order to be able to view the upper part of the cylinder.

### IMPORTANT

- If waste gets stuck and causes blockage around the intake air cooling vent or between the cylinder fins, it may cause the engine to overheat, and that in turn may cause mechanical failure on the part of the hedge-trimmer.




# Maintenance

---

## ■ PROCEDURES TO BE PERFORMED AFTER EVERY 100 HOURS OF USE

1. Remove the muffler, insert a screwdriver into the vent, and wipe away any carbon buildup. Wipe away any carbon buildup on the muffler exhaust vent at the same time.



2. Tighten all screws, bolts, and fittings.
3. Check to see if any oil or grease has worked its way in between the clutch lining and drum, and if it has wipe it away using oil-free, lead-free gasoline.

## ***Storage***

---

- Old fuel left in the carburetor can cause starting failure. Before storing the unit, empty the fuel tank and drain the carburetor with the priming pump equipped on it.

**HEDGE-TRIMMERS**

**HT2200  
CHT2200**

**NOTE :**


1. Use KOMATSU ZENOAH genuine parts as specified in the parts list for repair and/or replacement.
2. KOMATSU ZENOAH does not warrant the machines, which have been damaged by the use of any parts other than those specified by the company.
3. When placing parts orders for repair and/or replacement, check if the model name and the serial number are applicable to those specified in the parts list, then use parts number described in the parts list.
4. The contents described in the parts list may change due to improvement.
5. The parts for the machine shall be supplied seven (7) years after the machine is discontinued. [It is possible that some specific parts may be subject to change of their delivery term and list price within the limit of seven (7) years after the machine is discontinued. It is also possible that some parts may be available even after the limit of seven (7) years.]

APPLICABLE SERIAL NUMBERS :

Mar. 2001

HT2200	CUTTING UNIT 900101 and up	ENGINE UNIT 50100000 and up
CHT2200	CUTTING UNIT 900101 and up	ENGINE UNIT 50100000 and up

**Fig.1 CUTTER GROUP — HT2200**




# Parts List

**Fig.1 CUTTER GROUP — HT2200**

Key#	Description	Part Number	Q'ty	Note	Key#	Description	Part Number	Q'ty	Note
1	Gear case	T4001-31110	1						
2	Cover	T4001-31210	1						
3	Gasket	T4001-31220	1						
4	Drum	3884-11410	1						
5	Bearing	06004-06001	2						
6	Snap ring	T4001-31320	1						
7	Pinion	T4001-31330	1						
8	Bearing	T4001-31340	2						
9	Gear comp.	T4001-31350	1						
10	Rod	T4001-31510	2						
11	Snap ring	04064-02512	1						
12	Fitting	3199-13350	1						
13	Felt	T4001-31360	1						
14	Bolt	T4001-31370	6	M5x12					
15	Guide plate	T4001-32110	1						
16	Upper blade	T4001-32210	1						
17	Lower blade	T4001-32220	1						
18	Screw(L:19)	3884-11750	3						
19	Screw(L:29)	6095-11810	1						
20	Washer	3880-11780	4						
21	Nut	3880-11790	4						
22	Screw	T4001-32310	2	M5x16					
23	Nut	T4001-32320	2						
24	Cover, blade	T4001-32910	1						
25	Handle comp.	6844-12100	1						
26	• Grip	3880-13121	1						
27	Washer	3883-12130	1						
28	Bolt	3883-12140	1	M6x18					
29	Handle comp.	T4001-34100	1						
30	• Grip	3880-13121	1						
31	Switch	T4001-74100	1						
32	Screw	0263-00525	1						
33	Nut	0280-10504	1						
34	Tube	T4001-74310	1						
35	Lever assy	3881-13210	1						
36	Bolt	0212-50525	2						
37	Plate	6095-13310	1						
38	Nut	3876-14470	2						
39	Band	3880-13350	1						
40	Bolt	0225-10614	3						
41	Tool set	1111-91003	1						
42	• Spanner	3540-91120	1						
43	• Socket	1110-91320	1						
44	• Driver	1030-91340	1						
101	Receive plate	3885-91110	1	OP					
102	Wrench	3880-95020	1	OP					
103	Wrench	3880-95010	1	OP					

## Parts List

### Fig.2 ENGINE GROUP — HT2200






# Parts List

**Fig.2 ENGINE GROUP — HT2200**

Key#	Description	Part Number	Q'ty	Note	Key#	Description	Part Number	Q'ty	Note
1	Cylinder	5602-12110	1		60	• Rope	1861-75180	1	
2	Gasket, base	5500-12213	1		61	• Knob	1490-75181	1	
3	Bolt, M5x22	1850-12130	2		62	Screw	0263-90412	4	
4	Insulator	5500-13163	1		63	Bracket	5628-83221	1	
5	Gasket, insulator	5500-13121	1		64	Gasket, carburetor	5500-13131	1	
6	Gasket, carb	5500-13131	1		65	Carburetor assy	5602-81001	1	WYL-55
7	Screw, M5x20	0263-90520	2		66	• Screw	5850-81110	2	
8	Muffler assy	5602-15100	1		67	• Ring	1751-81130	1	
					68	• Swivel	1881-81140	1	
10	• Spark arrester	1601-15120	1		69	• Valve assy	_____	1	
11	Bolt, M5x50	01252-30550	2		70	• O-ring	1751-81240	1	
12	Gasket, muffler	5600-15210	1		71	• Jet #37	5628-81250	1	
13	Plate, muffler	5600-15220	1		72	• Rebuilt Kit	5602-06030	1	
14	Screw, M4x16	0263-90416	1		73	•• Body assy	1850-81450	1	
15	Crankcase comp.	5600-21100	1		74	••• Screen	_____	—	
16	Gasket, case	5500-21141	1		75	•• Gasket Kit	5602-06020	1	
17	Bearing	06030-06001	2		76	••• Diaphragm, pump	_____	—	
18	Oil seal	2169-21210	1		77	••• Gasket, pump	_____	—	
19	Oil seal	1850-21220	1		78	••• Diaphragm	_____	—	
20	Snap ring	04065-02812	1		79	••• Gasket, diaphragm	_____	—	
21	Bolt, M5x30	01252-30530	4		80	• Body, purge	1850-81490	1	
22	Guard	5500-22110	1		81	• Pump, priming	1751-81510	1	
23	Screw, M5x14	0263-90514	1		82	• Cover, pump	1850-81520	1	
24	Piston	5600-41111	1		83	• Screw	1850-81530	4	
25	Ring, piston	1100-41210	2		84	Screw	5500-85510	3	
26	Pin, piston	1101-41310	1		85	Label, recoil	T1038-91120	1	
27	Snap ring	1260-41320	2		86	Cap	1601-81810	1	
28	Bearing	5500-41410	1		87	Screw, M5x60	0263-90560	2	
29	Washer	1101-41340	2		88	Clip	1950-86120	1	
30	Crankshaft comp.	5600-42001	1		89	Body assy	5500-82102	1	
31	Nut	1650-43230	1		90	• Sleeve	1970-82190	2	
32	Key	1000-43240	1		91	• Plate, choke	5500-82131	1	
33	Shoe	1140-51111	2		92	• Lever, choke	5500-82140	1	
34	Screw	1140-51250	2		93	• Screw	2630-33610	1	
35	Spring	1600-51223	1		94	Element	5500-82171	1	
36	Washer	1140-51230	2		95	Cover assy	5600-82203	1	
37	Washer	1970-51241	2		96	• Knob	5500-82221	1	
38	Case, clutch	5600-52110	1		97	Cover, fan	5600-31110	1	
39	Screw, M5x16	0263-90516	4		98	Screw, M5x20	0263-90520	4	
40	Plate, clutch	5600-52150	1		99	Cover, engine	5600-32101	1	
41	Nut	1650-43230	1		100	Screw, M5x12	1850-32160	1	
42	Rotor	5601-71110	1		101	Screw	1900-31410	1	
43	Coil assy	5600-71200	1		102	Spark plug	5602-73110	1	RCJ6Y
44	• Cord	5600-71220	1		103	Grommet	1852-72121	1	
45	• Cap	2616-71320	1		104	Cord comp.	5500-73201	1	
46	Cap, spark plug	5500-72110	1						
47	Spring	1900-72120	1		106	Cable comp.	1751-82101	1	
48	Grommet	5500-72130	1		107	Tank assy	5607-85002	1	
49	Spacer	1260-71261	2		108	• Cap assy	5607-85201	1	
50	Bolt, M4x25	3310-72150	2		109	•• Packing	5500-85220	1	
51	Recoil assy	5990-75102	1		110	•• Holder	5601-85300	1	
52	• Case, recoil	5990-75110	1		111	•• Filter	5601-85260	1	
53	• Spring, Spiral	5990-75120	1		112	•• Stopper	4820-85260	1	
54	• Reel	5990-75131	1		113	• Pipe comp.	5500-85300	1	
55	• Ratchet	5990-75141	1		114	• Filter assy	5500-85400	1	
56	• Spring	5990-75151	1		115	• Clip	1260-85460	1	
57	• Screw	5990-75270	1		116	Clip	1950-86120	1	
58	• Retainer	5990-75160	1						
59	• Washer	5990-75170	1						

**Fig.3 CUTTER GROUP — CHT2200**




# Parts List

**Fig.3 CUTTER GROUP — CHT2200**

Key#	Description	Part Number	Q'ty	Note	Key#	Description	Part Number	Q'ty	Note
1	Gear case	T4002-31110	1						
2	Cover	T4002-31210	1						
3	Gasket	T4002-31220	1						
4	Drum	3884-11410	1						
5	Bearing	06004-06001	2						
6	Snap ring	T4001-31320	1						
7	Pinion	T4001-31330	1						
8	Bearing	T4001-31340	2						
9	Gear comp.	T4001-31350	1						
10	Rod	T4001-31510	2						
11	Snap ring	04064-02512	1						
12	Fitting	3199-13350	1						
13	Felt	T4001-31360	1						
14	Bolt	T4001-31370	7	M5x12					
15	Guide plate	T4002-32110	1						
16	Blade	T4002-32210	2						
17	Screw (L:19)	3884-11750	4						
18	Washer	3880-11780	4						
19	Nut	3880-11790	4						
20	Screw	T4001-32310	2	M5x16					
21	Nut	T4001-32320	2						
22	Cover, blade	T4002-32910	1						
23	Handle (Front)	T4002-33110	1						
24	Bolt	0225-30635	2						
25	Nut	0280-10605	2						
26	Handle (Rear) Assy	6845-13100	1						
27	• Switch	6845-13130	1						
28	• Pin	3873-13140	1						
29	• Spring	3873-13150	1						
30	• Cap	3873-13160	1						
31	• Plate	3873-13170	1						
32	• Screw	3873-13180	1						
33	• Wire end	3873-13210	1						
34	• Lever	3873-13221	1						
35	• Snap ring	3873-13230	1						
36	• Stopper	6845-13310	1						
37	• Spring	6845-13320	1						
38	• Screw	3873-13240	5						
39	• Screw	3873-13250	1						
40	• Nut	0280-10403	6						
41	Bolt	0225-50650	1						
42	Nut	0280-10605	1						
43	Bolt	0225-50640	1						
44	Bolt	0225-10614	2						
45	Tool set	1111-91003	1						
46	Spanner	3540-91120	1						
47	Socket	1110-91320	1						
48	Driver	1030-91340	1						
101	Wrench	3880-95020	1	OP					
102	Wrench	3880-95010	1	OP					

# Parts List

**Fig.4 ENGINE GROUP — CHT2200**



# Parts List

**Fig.4 ENGINE GROUP — CHT2200**

Key#	Description	Part Number	Q'ty	Note	Key#	Description	Part Number	Q'ty	Note
1	Cylinder	5602-12110	1		60	• Rope	1861-75180	1	
2	Gasket, base	5500-12213	1		61	• Knob	1490-75181	1	
3	Bolt, M5x22	1850-12130	2		62	Screw	0263-90412	4	
4	Insulator	5500-13163	1		63	Bracket	5628-83221	1	
5	Gasket, insulator	5500-13121	1		64	Gasket, carburetor	5500-13131	1	
6	Gasket, carb	5500-13131	1		65	Carburetor assy	5602-81001	1	WYL-55
7	Screw, M5x20	0263-90520	2		66	• Screw	5850-81110	2	
8	Muffler assy	5603-15100	1		67	• Ring	1751-81130	1	
9	• Muffler	5603-15110	1		68	• Swivel	1881-81140	1	
10	• Spark arrester	1601-15120	1		69	• Valve assy	_____	1	
11	Bolt, M5x50	01252-30550	2		70	• O-ring	1751-81240	1	
12	Gasket, muffler	5600-15210	1		71	• Jet #37	5628-81250	1	
13	Plate, muffler	5600-15220	1		72	• Rebuilt Kit	5602-06030	1	
14	Screw, M4x16	0263-90416	1		73	•• Body assy	1850-81450	1	
15	Crankcase comp.	5600-21100	1		74	••• Screen	_____	—	
16	Gasket, case	5500-21141	1		75	•• Gasket Kit	5602-06020	1	
17	Bearing	06030-06001	2		76	••• Diaphragm, pump	_____	—	
18	Oil seal	2169-21210	1		77	••• Gasket, pump	_____	—	
19	Oil seal	1850-21220	1		78	••• Diaphragm	_____	—	
20	Snap ring	04065-02812	1		79	••• Gasket, diaphragm	_____	—	
21	Bolt, M5x30	01252-30530	4		80	• Body, purge	1850-81490	1	
22	Guard	5500-22110	1		81	• Pump, priming	1751-81510	1	
23	Screw, M5x14	0263-90514	1		82	• Cover, pump	1850-81520	1	
24	Piston	5600-41111	1		83	• Screw	1850-81530	4	
25	Ring, piston	1100-41210	2		84	Screw	5500-85510	3	
26	Pin, piston	1101-41310	1		85	Label, recoil	T1041-91120	1	
27	Snap ring	1260-41320	2		86	Cap	1601-81810	1	
28	Bearing	5500-41410	1		87	Screw, M5x60	0263-90560	2	
29	Washer	1101-41340	2		88	Clip	1950-86120	1	
30	Crankshaft comp.	5600-42001	1		89	Body assy	5500-82102	1	
31	Nut	1650-43230	1		90	• Sleeve	1970-82190	2	
32	Key	1000-43240	1		91	• Plate,choke	5500-82131	1	
33	Shoe	1140-51111	2		92	• Lever, choke	5500-82140	1	
34	Screw	1140-51250	2		93	• Screw	2630-33610	1	
35	Spring	1600-51223	1		94	Element	5500-82171	1	
36	Washer	1140-51230	2		95	Cover assy	5600-82203	1	
37	Washer	1970-51241	2		96	• Knob	5500-82221	1	
38	Case, clutch	5600-52110	1		97	Cover, fan	5600-31110	1	
39	Screw, M5x16	0263-90516	4		98	Screw, M5x20	0263-90520	4	
40	Plate, clutch	5600-52150	1		99	Cover, engine	5600-32101	1	
41	Nut	1650-43230	1		100	Screw, M5x12	1850-32160	1	
42	Rotor	5601-71110	1		101	Screw	1900-31410	1	
43	Coil assy	5600-71200	1		102	Spark plug	5602-73110	1	RCJ6Y
44	• Cord	5600-71220	1		103	Grommet	1852-72121	1	
45	• Cap	2616-71320	1		104	Cord comp.	5601-73200	1	
46	Cap, spark plug	5500-72110	1		105	Clamp	848-8K4-0010	1	
47	Spring	1900-72120	1		106	Cable comp.	5601-83100	1	
48	Grommet	5500-72130	1		107	Clamp	848-8K4-0010	1	
49	Spacer	1260-71261	2		108	Tank assy	5607-85002	1	
50	Bolt, M4x25	3310-72150	2		109	• Cap assy	5607-85201	1	
51	Recoil assy	5990-75102	1		110	•• Packing	5500-85220	1	
52	• Case, recoil	5990-75110	1		111	•• Holder	5601-85300	1	
53	• Spring, Spiral	5990-75120	1		112	•• Filter	5601-85260	1	
54	• Reel	5990-75131	1		113	•• Stopper	4820-85260	1	
55	• Ratchet	5990-75141	1		114	• Pipe comp.	5500-85300	1	
56	• Spring	5990-75151	1		115	• Filter assy	5500-85400	1	
57	• Screw	5990-75270	1		116	• Clip	1260-85460	1	
58	• Retainer	5990-75160	1		117	Clip	1950-86120	1	
59	• Washer	5990-75170	1						

## RedMax LIMITED WARRANTY

**EMISSION-RELATED PARTS**, FOR TWO (2) YEARS FROM THE DATE OF ORIGINAL DELIVERY OF THE UNIT, KOMATSU ZENOAH AMERICA INC. (THE COMPANY), THROUGH ANY RedMax DEALER, WILL REPAIR OR REPLACE, FREE OF CHARGE, FOR THE ORIGINAL AND EACH SUBSEQUENT PURCHASER, ANY PART OR PARTS FOUND TO BE DEFECTIVE IN MATERIAL AND/OR WORKMANSHIP. EMISSION-RELATED PARTS ARE:

**THE CARBURETOR ASSY, COIL ASSY, ROTOR, SPARKPLUG,  
AIR FILTER, FUEL FILTER, INTAKE MANIFOLD, AND THE GASKETS**

**ALL OTHER PARTS EXCEPT ABOVE PARTS**, FOR TWO (2) YEARS OF USE, 90 DAYS FOR RENTAL USE, FROM THE DATE OF ORIGINAL PURCHASE, THE COMPANY, THROUGH ANY RedMax DEALER, WILL REPAIR OR REPLACE, FREE OF CHARGE, FOR THE ORIGINAL PURCHASER, ANY PART OF PARTS FOUND TO BE DEFECTIVE IN MATERIAL AND/OR WORKMANSHIP. **THIS IS THE EXCLUSIVE REMEDY.**

THE PURCHASER SHALL BEAR COSTS OF TRANSPORTING THE UNIT TO AND FROM THE RedMax DEALER.

THE PURCHASER SHALL NOT BE CHARGED FOR DIAGNOSTIC LABOR WHICH LEADS TO THE DETERMINATION THAT A WARRANTED PART IS DEFECTIVE, IF THE DIAGNOSTIC WORK IS PERFORMED AT THE RedMax DEALER.

THE PURCHASER OR OWNER IS RESPONSIBLE FOR THE PERFORMANCE OF THE REQUIRED MAINTENANCE AS DEFINED BY THE MANUFACTURER IN THE OWNER/OPERATOR MANUAL.

ANY WARRANTED PART WHICH IS NOT SCHEDULED FOR REPLACEMENT AS REQUIRED MAINTENANCE, OR WHICH IS SCHEDULED ONLY FOR REGULAR INSPECTION TO THE EFFECT OF "REPAIR OR REPLACE AS NECESSARY" SHALL BE WARRANTED FOR THE WARRANTY PERIOD. ANY WARRANTED PART WHICH IS SCHEDULED FOR REPLACEMENT AS REQUIRED MAINTENANCE SHALL BE WARRANTED FOR THE PERIOD OF TIME UP TO THE FIRST SCHEDULED REPLACEMENT POINT FOR THE PART.

ANY REPLACEMENT PART THAT IS EQUIVALENT IN PERFORMANCE AND DURABILITY MAY BE USED IN NON-WARRANTY MAINTENANCE OR REPAIRS, AND SHALL NOT REDUCE THE WARRANTY OBLIGATION OF THE COMPANY.

THE COMPANY IS LIABLE FOR DAMAGES TO OTHER ENGINE COMPONENTS CAUSED BY THE FAILURE OF A WARRANTED PARTS STILL UNDER WARRANTY.

**THE WARRANTY DOES NOT APPLY** TO THOSE UNITS WHICH HAVE BEEN DAMAGED BY NEGLIGENCE OF INSTRUCTION LISTED IN THE OWNER/OPERATOR MANUAL FOR PROPER USE AND MAINTENANCE OF THE UNITS, ACCIDENTAL MISHANDLING, ALTERATION, ABUSE, IMPROPER LUBRICATION, USE OF ANY PARTS OR ACCESSORIES OTHER THAN THOSE SPECIFIED BY THE COMPANY, OR OTHER CAUSES BEYOND THE COMPANY'S CONTROL.

**THIS WARRANTY DOES NOT COVER** THOSE PARTS REPLACED BY NORMAL WEAR OR HARMLESS CHANGES IN THEIR APPEARANCE.

**THERE ARE NO OTHER EXPRESS WARRANTIES.**

**IMPLIED WARRANTIES** INCLUDING THOSE OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE **ARE LIMITED** TO TWO (2) YEARS OF USE FROM THE ORIGINAL DELIVERY DATE.

**LIABILITIES FOR INCIDENTAL OR CONSEQUENTIAL DAMAGE UNDER ANY AND ALL WARRANTIES ARE EXCLUDED.**

SOME STATES DO NOT ALLOW LIMITATION ON HOW LONG AN IMPLIED WARRANTY LASTS OR EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATION OR EXCLUSION MAY NOT APPLY TO YOU.

THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY ALSO HAVE OTHER RIGHTS WHICH VARY FROM STATE TO STATE.

IF YOU NEED TO OBTAIN INFORMATION ABOUT THE NEAREST SERVICE CENTER, PLEASE CALL KOMATSU ZENOAH AMERICA INC. AT (770)-381-5147.

**IMPORTANT:** YOU WILL RECEIVE A WARRANTY REGISTRATION CARD AT TIME OF PURCHASE. PLEASE FILL OUT THE CARD AND SEND IT TO RedMax / KOMATSU ZENOAH AMERICA WITHIN SEVEN (7) DAYS. BE SURE TO KEEP A COPY FOR YOUR RECORDS.



KOMATSU ZENOAH AMERICA INC.  
4344 Shackelford Road Suite 500  
Norcross, Georgia 30093

## RedMax

### Garantie limitée

**Pièces en rapport avec les émissions de gaz d'échappement :** KOMATSU ZENOAH AMERICA INC., par l'intermédiaire de n'importe quel revendeur RedMax, réparera gratuitement ou remplacera gratuitement pour l'acheteur initial et chaque acheteur successif toute(s) pièce(s) se révélant de constitution et/ou de montage défectueux pendant deux (2) ans à compter de la date initiale de livraison d'une unité. Les pièces en rapport avec les émissions de gaz d'échappement sont:

**l'assemblage carburateur, l'assemblage bobine, le rotor, la bougie,  
le filtre à air, le filtre à carburant, la tubulure d'admission et les joints**

**Toutes les pièces autres que celles mentionnées ci-dessus**, deux (2) ans d'utilisation, 90 jours pour la location, à compter de la date d'achat initial. La société, par l'intermédiaire d'un distributeur RedMax, réparera ou remplacera toute(s) pièce(s), sans frais et au bénéfice de l'acheteur original, en prenant en charge les frais de pièces et/ou de main d'œuvre. **Telles sont les limites de la garantie.**

Le coût du transport de l'unité jusqu'au revendeur RedMax et depuis celui-ci sera à la charge de l'acheteur.

L'acheteur ne supportera pas le coût de main d'œuvre du diagnostic qui amène à la conclusion qu'une pièce garantie est défectueuse, si ce diagnostic est effectué chez le revendeur RedMax.

L'acheteur ou propriétaire a pour responsabilité d'effectuer l'entretien obligatoire tel que défini par le fabricant dans le manuel du propriétaire/de l'utilisateur.

Toute pièce garantie dont le remplacement n'est pas prévu dans le cadre de l'entretien obligatoire, ou pour laquelle est seulement prévue une inspection périodique pour "remplacement ou réparation si nécessaire" sera garantie pour la période de garantie. Toute pièce garantie arrivée à l'échéance de son premier remplacement prévu sera garantie jusqu'à celui-ci.

Toute pièce de rechange équivalente en performance ou en durabilité peut être utilisée pour l'entretien hors-garantie ou les réparations hors-garantie, et ce sans réduire l'obligation de garantie incombant à la société.

La société sera tenue responsable des dommages aux autres composants du moteur causés par la défaillance de pièce(s) garantie(s) en période de garantie.

**La garantie ne s'applique pas** aux unités endommagées par suite de: négligence dans la mise en oeuvre des instructions spécifiées dans le manuel du propriétaire/de l'utilisateur en vue d'une utilisation et d'un entretien correct, fausse manœuvre accidentelle, modification, utilisation abusive, lubrification incorrecte, utilisation de pièces ou d'accessoires autres que ceux spécifiés par la société, ou autres causes hors du contrôle de la société.

**Cette garantie ne couvre pas** les pièces remplacées en raison de leur usure normale ou de changements d'apparence sans effets.

**Il n'existe aucune autre garantie explicite.**

**Les garanties implicites**, y compris la valeur marchande et la valeur d'usage pour une utilisation particulière, **sont limitées** à deux (2) ans d'utilisation à compter de la date originale de livraison.

**Les responsabilités pour les dommages conséquents ou incidents sont exclues de toutes les garanties.**

Certaines provinces n'autorisant pas les limitations à la durée des garanties implicites, ou les exclusions ou limitations relatives aux dommages incidents ou conséquents, la limitation indiquée ci-dessus peut ne pas vous être applicable.

Cette garantie vous donne des droits juridiques spécifiques, et vous pouvez également jouir d'autres droits variant d'une province à l'autre.

Si vous désirez obtenir des informations sur le centre de service le plus proche, veuillez appeler KOMATSU ZENOAH AMERICA INC. au (770)-381-5147

**Note importante:** vous recevrez une carte d'enregistrement de garantie au moment de l'achat. Veuillez la remplir et l'adresser à RedMax / KOMATSU ZENOAH AMERICA sous sept (7) jours en prenant soin de conserver une copie pour vous.



KOMATSU ZENOAH AMERICA INC.  
4344 Shackleford Road Suite 500  
Norcross, Georgia 30093



KOMATSU ZENOAH AMERICA INC.  
4344 Shackleford Road Suite 500  
Norcross, Georgia 30093